SCHEMATIC DIAGRAM

RX-402



ITEM	SCHEMATIC LOCATION (LAST)	
AM/FM IF AMP	R162	C153
FM MPX DECODER	R313	C318
EQUALIZER AMP	R421	C417
TONE CONTROL AMP.	R542	C534
MAIN AMP.	R668	C622
POWER SUPPLY	R906	C908
CHASSIS	R005	C002

ROTEL Dahl Elektronik GmbH, Postfach 70 16 29, D-2000 Hamburg 70